


How to Build a Network Cabinet

1. Pull cabinet out of package and make sure holes are on your left and latch is on your right.
 - a. Untie the plastic cover from the back, it needs to be put back on the cabinet when complete, so do not ruin it.
2. Remove the silver bolts on the sides and flip (180 degrees) the screw strips on each side of the cabinet.



BEFORE



AFTER

3. Insert Patch Panel (one for non-drive thru stores/two for drive thru stores)
 - a. Goes in top three screw holes. (Use little black screws)



PATCH PANEL INSERTED VIEW

4. Insert power strip right below patch panel(s)



POWER STRIP INSERTED VIEW

5. Insert first (Top) shelf
 - a. Count down three screw holes from power strip and screw shelf into fourth hole.
6. Insert second (Bottom) shelf
 - a. Count down three screw holes from first shelf and screw shelf into fourth hole.



FIRST SHELF INSERTED VIEW



BOTH SHELVES INSERTED VIEW

7. Insert Caller ID box

- a. First, Configure caller ID...(See Caller ID Config. instructions attached)
- b. Cut Velcro strip in half and attach to bottom of caller ID box.
- c. Place caller ID on first (top) shelf to the left.



CALLER ID INSERTED VIEW

8. Insert NetGear Switch

- a. Configure the Netgear switch...(See Netgear Config. Instructions attached)
- b. Screw on side brackets to Netgear switch
- c. Screw Netgear switch in between the first and second shelf



NETGEAR INSERTED VIEW

9. Hook up the wires
 - a. Connect power supply to Caller ID box and plug into power strip
 - b. Zip tie power strip cord to top of cabinet
 - c. Connect Ethernet cable from back of caller ID box to front of the Netgear Switch (Port 45)




BACK OF CALLER ID BOX VIEW

- d. Then zip tie ethernet cable down along back of top shelf.



- e. Zip tie two (2) steel wall plates to the front of bottom shelf



NOTE: (ONLY JIMMY JOHNS) IF JJ store has any wall mounted Verifone units, you must zip tie wall mounts to cabinet as well for shipment. One wall mount for each Verifone wall station.

COMPLETE CABINET FRONT VIEW



Caller ID Configuration Instructions

1. Click on "Shortcut to ELSETUP" Icon on desktop
2. On Caller ID unit turn #8 and #9 switches up (All others should be down)
3. Plug in cord from switch #6 into back of Caller ID unit
4. Plug in power cord to Caller ID unit
5. Click "change" next to IP Address field & change to 192.168.1.253 and update
6. Click "change" next to Port and make it 6699 and update
7. Click "refresh"

Netgear Switch Configuration Instructions

1. Connect Netgear to power supply
2. Connect to network with cord
3. Wait for the power light to turn green on the front of the switch (will show as orange first)
4. Click on "Smart Control Center Management" desktop icon
 - a. Click "Discover" (bottom right)
 - b. Click "Maintenance" (top)
 - c. Click on the device listed
 - i. Click "download configuration" (bottom right)
 - ii. Select "Startup_Config_48.cfg" from folder
 - iii. Enter in Password: password (all lower case)
 - iv. Click "Apply" (bottom right)
 - d. Click on "tasks" tab at top
 - i. Wait for it to read "successfully completed"
 1. Sometimes you have to click between tasks and maintenance for it to come up.